
S45-1180 Direct Fill with Drain Back







S45-1180 Direct Fill with Drain Back



Caution: Adequate safety measures and PPE must be employed.




Fit the 1/2 BSP Cone Faced Adaptor to the welded 1/2" BSP Socket welded on the 4" BSP Socket. Then fit the 4" BSP Socket to the 4"Fill Riser.





Fit the sump at the correct height.

IMPORTANT! The base of the sump must be adequately supported on concrete. The sump **MUST NOT** be suspended on the sump PSB-110-PS Viton Gaiter Seal.




S45-1180 Direct Fill with Drain Back






when the Fill Cap and Adaptor is fitted the top of the cap is 2" below the bottom of the FL180 Access Cover.





FIBRELITE




NB:- At this stage the Fill Riser can be plugged off and the system vacuum tested. The system must only be tested at 24".


S45-1180 Direct Fill with Drain Back







FIBRELITE



S45-1180 Direct Fill with Drain Back



